



# Gantry images


wl\_dir/WL G=0, C=0, P=0;  
Field=(40, 40)mm; BB=4mm @  
left=0, in=0, up=0; Gantry  
tilt=0, Gantry sag=0.dcm



wl\_dir/WL G=90, C=0, P=0;  
Field=(40, 40)mm; BB=4mm @  
left=0, in=0, up=0; Gantry  
tilt=0, Gantry sag=0.dcm



wl\_dir/WL G=180, C=0, P=0;  
Field=(40, 40)mm; BB=4mm @  
left=0, in=0, up=0; Gantry  
tilt=0, Gantry sag=0.dcm



wl\_dir/WL G=270, C=0, P=0;  
Field=(40, 40)mm; BB=4mm @  
left=0, in=0, up=0; Gantry  
tilt=0, Gantry sag=0.dcm

